



**INSTALL PER MANUFACTURER'S RECOMMENDATIONS

GENERAL NOTES:

FOR HEAVY DUTY CORRIDORS, EDGE DRAINS SHALL BE PLACED ON BOTH SIDES OF THE PAVEMENT. EDGE DRAINS SHALL BE PLACED ONLY ON THE OUTSIDE PAVEMENT EDGE FOR LIGHT AND MEDIUM DUTY CORRIDORS.

PAVEMENT UNDERDRAINAGE

REHABILITATED PROJECTS FOR PCC UNBONDED OVERLAYS AND HOT MIX ASPHALT OVERLAYS ON RUBBLIZED PCC

SPECIAL SHEET